



**phigenics**

Smart Water Management

## **SWAB COLLECTION PROCEDURE**

- Remove the swab from the sterile tube.
- Collect sample by rubbing the swab over the sample area, reversing directions between strokes. Repeat four more times over the same surface area.
- Immediately replace the swab into the neutralizing buffer, making sure cap is tightly closed.
- Affix tube with a completed location label.
- Ship sample overnight to:

Phigenics Analytical Services Laboratory  
1701 Quincy Ave., Suite 32  
Naperville, IL 60540